
BT



Games Service

User guide

INTERACTIVE TV

Now BT Interactive TV brings you the Games service – a selection of the best video games whenever you want to play them.

Games choice
Some of the top Nintendo Super NES games around – whenever you want.

Interactive tips and tricks
Send us your games tips and tricks and see them on screen.

Check the tips and tricks for help with the games you play.

Choose which TV to use
You can play the games on any TV in your home and play the game just as if you had bought the Nintendo Game Pak.


At a glance

BT GameCart

Stores the games from the BT Interactive TV Service

BT GameCart cable


Connects to the BT Interactive TV System when you download games



To power

Super NES

Aerial to Nintendo switch box or TV for playing games




BT Interactive TV System

BT GameCart cable connection for downloading games


To Super NES

To TV




Nintendo switch box

To BT Interactive TV System



BT Interactive TV System

BT GameCart cable connection for downloading games



Nintendo switch box

To BT Interactive TV System

In this guide

Setting up 4

Basics 5

– Downloading games 5

– Playing time 6

– Age ratings 6

– Starting games 7

Extras 8

Technical 9

Help 10

Hints and tips

Helpful hints and tips to help you get the most from the BT Interactive TV Games Service are in grey boxes.

Setting up *This section shows you how to connect the Nintendo switch box so that you can play games on the same TV you use for BT Interactive TV*


You need to connect the Nintendo switch box if you intend to play your games on the same TV that is connected to your BT Interactive TV System. You don't need to connect the Nintendo switch box if you are going to take your Super NES to a different TV to play the games.

To connect the Nintendo switch box

1 Switch off your TV

2 Disconnect the UHF cable from the aerial socket on the back of your TV

3 Connect the UHF cable to the **AER** socket on the Nintendo switch box



4 Connect the Nintendo switch box to your TV with the extension cable

5 Switch the Nintendo switch box to **AER**

6 Switch on your TV


Basics *This section shows you how to download and play games – downloading stores the game on your BT GameCart*

Downloading games


1 Plug your Super NES into the power socket

2 Plug the BT GameCart into your Super NES

The Super NES power switch must be off before you can plug in the GameCart.




3 Connect the GameCart cable to your BT Interactive TV System and GameCart – the GameCart plug is labelled



4 Switch the switch box to **AER**

BT Interactive TV will be able to tell you when the game is ready for you to play.



5 Switch on the BT Interactive System, TV and Super NES

6 Sign on and wait for the Home Screen

7 Choose **6 – Games Service**

From the screen you can choose:

- *the Nintendo Game Zone*
- *Tips and tricks*

8 Highlight the game you want to play and press **OK**

9 Choose **Play** or **Pay and Play**

For Pay and Play enter your PIN.

10 Follow the on-screen instructions

11 Press **Start**

BT Interactive TV will tell you when the download is complete – this usually takes between two and four minutes but sometimes takes longer.

12 Choose **Backtrack** to leave the Games Service

Playing time

When you've downloaded a game, it can be played for the time shown on the Pay and play screen. If you want to play the game at the end of this time, you will need to download it again.

An on-screen message will tell you when the game has expired.

Pay as you play

You can download the games you chose as many times as you like during the period you have paid for.

Subscription

You can download the games free of charge at any time (some premium items are charged separately).

Age-ratings

BT is a member of the European Leisure Software Publishers Association (ELSPA) and complies with ELSPA's voluntary age-rating classification for video games.

The age-rating logo on the detail screen shows which ages each game is suitable for.



Player ages


BT Interactive TV will not allow players to download games which have an older ELSPA age-rating than the players age.

Starting games on the TV connected to your BT Interactive TV System

1 Plug your Super NES into the power socket


2 Plug the BT GameCart into your Super NES

The Super NES power switch must be off before you can plug in the GameCart.



3 Connect the Super NES RF cable to the **Game** socket on the Nintendo switch box

There are instructions on page 8 about how to use a SCART connection with your Super NES.



4 Switch the Nintendo switch box to **Game**

5 Connect the other end of the Super NES RF cable to the **OUT** socket on your Super NES

6 Switch on the TV and Super NES

7 Switch the TV to your games channel and start the game as normal

Starting games on other TVs

You start games in just the same way as you do with your normal Nintendo games cartridges.

Reading the instructions for games

You can read the instructions for a game before you download it as well as after. Choose **Game Guide** to read the instructions.

Extras *Using a SCART with your Super NES and BT Interactive TV System*

Using a SCART with your Super NES

You will need an adaptor to connect the SCART lead to the **MULTI OUT** socket on your Super NES.

To use a SCART on a TV with one SCART socket

You need to do this through your video recorder.

1 Plug the adaptor into the **MULTI OUT** socket on your Super NES

2 Connect the adaptor to your video recorder **SCART IN** socket with a SCART cable

3 Connect the BT Interactive TV System **SCART 2 OUT** socket to the TV **SCART IN** socket

To use a SCART on a TV with two SCART sockets

1 Plug the adaptor into the **MULTI OUT** socket on your Super NES

2 Connect the BT Interactive TV System **SCART 2 OUT** socket to the TV **SCART 1 IN** socket with a SCART cable

Technical

Guidelines for playing video games

- If you are playing for a long time, take a 10 to 15 minute break every hour.
- Sit at least three metres from the TV screen.
- If you have an epileptic condition, consult your doctor before playing video games.
- Consult your doctor if you experience any of the following while playing:
  - altered vision
  - muscle twitches
  - involuntary movements
  - loss of awareness of your surroundings
  - mental confusion
  - convulsions.

Super NES safety

Only use the adaptor provided with your Super NES. It is normal for the adaptor to become warm when it is plugged in.

Only use the aerial switch box provided with your Super NES.

Do not take the Super NES or BT GameCart apart or try to repair them. Your warranty is void if you do this.

Always turn off the power switch before loading or removing the BT GameCart. The GameCart cannot be removed if the power switch is on.

Do not force the BT GameCart into the Control deck.

Insert the BT GameCart completely.

Remove the BT GameCart from the Control deck when you have finished playing.

Store the Control deck in a dry place, away from the floor or anywhere that it can collect dirt, dust, lint etc.

Do not drop, hit, or otherwise abuse the Super NES.

Do not leave the Super NES switched on when not in use.

Do not step on, sharply pull or bend any wires or cables.

Turn off the Super NES before unplugging from the power. Pull the plug from the socket – do not pull the lead.

Keep the Super NES and BT GameCart away from extreme heat or cold.

Do not spill liquid on the Super NES or BT GameCart. To clean use a cloth slightly dampened with water and do not use until completely dry. Do not use anything other than water to clean.

Do not rapidly turn the power switch on and off.

Do not touch the BT GameCart connectors. Do not blow on them or allow them to get wet or dirty.

Store the BT GameCart in its protective cover when not in use.

Check the BT GameCart connectors before inserting in the Super NES.

Do not dispose of the BT GameCart in a fire.

Help *This section helps you to solve any problems you may have using the Games service*

Help

The **HELP** button displays on-screen reminders of how to carry out particular tasks. You may be able to solve a problem without reading any further. Press **HELP** again to clear the reminders.

Problems and solutions

The game has not downloaded

- Check that all the cables are securely connected
- Check that your system is set up correctly
- Check that all the equipment is connected to the power and the power is on.

The Games service is not available from the Home Screen

Your account may not have been set up correctly. Please call the BT Interactive TV Helpline on **Free***fone 0800* **393 654**.

Downloading is taking a long time

Downloading normally takes between two and four minutes. Occasionally it may take longer because of interference.

The playing time finishes early

The battery in the BT GameCart may be low. Your Super NES should give you an on-screen message telling you this.

Call the Helpline on **Free***fone 0800* **393 654** for a new GameCart. We will send you a pre-paid envelope to return your old GameCart to us. Do not try to open the GameCart or dispose of it in fire.

You are locked out of the system

If you enter the wrong Personal Number three times, the System will lock you out. Please call the BT Interactive TV Helpline on **Free***fone 0800* **393 654**.

Further help and fault reporting

If you find these solutions do not help, you can call the BT Interactive TV Helpline on **Free***fone 0800* **393 654**, 24 hours a day, 7 days a week.

For help with your Nintendo equipment, call the Nintendo Service Centre on 01703 623 200, 9am to 5pm on Monday to Friday, and from 10am to 3pm on Saturdays and Bank Holidays.

Helpline services

Adding users, removing users, or changing your password

If you want to add or remove users, or change your password, please write to:

The Customer Service Manager
BT Interactive TV Trial
Cambridge Trunks Exchange
109-117 Long Road
Cambridge
CB2 2HG

Fax number 01223 845 384

Bill enquiries

Call BT Interactive TV Accounts on **Free***fone 0800* **671 477**. We may ask for your password and other information for our security checks.

Subscription Payment Option

To take up or cancel a monthly subscription, please call BT Interactive TV Accounts on **Free***fone 0800* **671 477**.
The minimum period for any subscription is one month and must be paid one month in advance.

If you pay a monthly subscription for a service, the price for items in that service will be shown on-screen as zero (there are charges for some premium items). Your bill will still itemise your use of the services.

Changing a user's Age classification

Every user has their own Age classification which controls the services they have access to. If you want to change a user's Age classification, please call BT Interactive Accounts on **Free***fone 0800* **671 477**.



Offices in Europe, North America, Japan and Asia Pacific.

The telecommunications services described in this publication are subject to availability and may be modified from time to time. Services and equipment are provided subject to British Telecommunications plc's respective standard conditions of contracts. Nothing in this publication forms any part of any contract.

© British Telecommunications plc 1996
Registered office: 81 Newgate Street, London EC1A 7AJ
Registered in England No: 1800000
Produced by BT Customer Communications Unit
Designed by Information Design Unit
Printed in England by Alpine Press. PHME 24512/3/1996

Printed on paper that is environmentally assessed **ECO-CHECK** ★★★★★